

# VIBE BOARD INSTRUCTIONS


The Vibe Board allows you to:

- Join a meeting on Google Meet, Teams or Zoom.
- Cast content from another device, including Windows and Mac/iOS devices and Chromebooks.
- Take notes, like a whiteboard.

---


## JOIN A MEETING

1. Tap **Join** at the bottom of the home screen.



2. Enter your **meeting ID**.
  - Enter a **passcode**, if required.

3. Tap **Continue** to launch the meeting.



# CAST CONTENT TO THE VIBE BOARD

The Vibe Board offers multiple ways to screen share.


- Tap **Vibe cast** at the bottom of the home screen.
- Then, follow the instructions based on your device:

---

## Windows device

On your Windows device:

1. Connect to the **“Vibe”** Wi-Fi network.
2. Open **<https://one.vibe.us>**
3. Select the correct board from the list (e.g., SMSTUDYROOM1).



---

## Mac/iOS device

On your MacBook, iPhone or iPad:

1. Connect to the **“Vibe”** Wi-Fi network.
2. Enable Screen Mirroring: Use AirPlay or the **Screen Mirroring** option in the Control Center.
3. Select the correct board from the list.



---

## Chromebook


On your Chromebook:

1. Connect to the **“Vibe”** Wi-Fi network.
2. Open **<https://one.vibe.us>**
3. Select the correct board from the list (e.g., SMSTUDYROOM1).



## Vibe Tap


1. Plug in the Vibe Tap:
  - Plug the Vibe Tap into the Vibe Board's USB-C port (to the left on the back of the board).
  - Plug the Vibe Tap into the USB-C port on your device.
2. Tap to share:
  - After plugging in the Vibe Tap, tap the button to start screen sharing.



---

## HDMI/USB-C

1. Locate ports on the back of the Vibe Board:
  - USB-C: Use for both video and touchback capability.
  - HDMI: Use for 4K video and audio input.
2. Plug in your device:
  - Connect your device using the appropriate cable.
  - Switch the input on the Vibe Board if needed.



---

## CLEAR SESSION

- At the end of your session, tap **Clear Session** on the Vibe Board to remove personal data.
- If board is unused for 30 minutes, the session will automatically be cleared.